

# MTA TIG START 300 slope

**TIG box which will connect onto constant current stick welding power sources to give tig functions including control of the welding current, provide up and down slope of the welding current HF start and other tig functions. Gives excellent Tig welding performance Can be used on inverters, engine driven welder generators or conventional rectifier type power sources to weld stainless steel, mild steel, and copper etc**

## Standard functions / features

- Amperage control, with remote socket to connect footpedal or remote if required.
- Upslope and downslope of welding current.
- Torch trigger normal and latching functions.
- TIG / MMA switch so stick welding can also be carried out through the box.
- Gas post flow adjustment to give a good finish without contamination to weld.
- Gas flow meter fitted
- Electronic HF to start the welding arc.
- 3/8 BSP gas and power connection to take standard tig torches.
- Heavy duty inbuilt contactor to start and stop the welding arc.
- Works with mma power sources from 45 volts to 110 volts output.
- Other functions are available like ammeter, etc if required.



## Technical specification

- Current range (depending on power source) 5A – 300A
- Duty cycle 230A/60% 300A/35%
- OCV range 45 V – 110V AC/DC
- Aux volts 110V or 24V 50va

**Price Beat!**

*- If you can find the models we list at a better price, ring us now! We'll try to beat it (Proof of price required)*

**migtigarc**  
SALES - HIRE - REPAIRS

TE/FAX 023 9229 5612  
WWW.MIGTIGARC.CO.UK

261-263 MILTON ROAD, SOUTHSEA, HANTS P04 8PQ

*Silver solder, welding curtains, gas rods, cutting & grinding discs, pickling paste, trolleys, safety footwear etc*